

! IMPORTANT!

We recommend mounting Ascent C1 inside the gate operator or other weatherproof enclosure when possible.

If mounting inside a metal enclosure, the **Ascent 10' Cable Extension** (p/n 16-X-EXT) is required. Follow the instructions included with the cable extension before moving on. **Failure to do so may result in no signal!**

Continued on next page...

(!) IMPORTANT!

Ascent **WILL NOT WORK** until the activation process is **COMPLETE**!


Follow the **Activation Guide** or call **Summit Control** at **(844) 259-8265** to activate your unit.


• WARNING!

AUTOMATIC GATES CAN CAUSE SERIOUS INJURY OR DEATH!

ALWAYS CHECK that the GATE PATH IS CLEAR BEFORE OPERATING!

Reversing or other safety devices should **ALWAYS BE USED!**








Before proceeding, double check that wiring is correct and unit has power!

For additional wiring options, see **page 3**.









INSTALLATION COMPLETE!

Now follow the **Activation Guide** to create an account and begin using Ascent.

© 2016 Security Brands, Inc. QSG-25C1-EN Rev. C (11/2016)





Using a
Third-Party
Power Source
(Optional)

! IMPORTANT!

If you would like to use a third-party

power source, such as solar, verify that it conforms to the following specs:

Input

12-24 VAC/DC no more than 10% under or over

Current Draw

less than 90 mA @ 12 VDC less than 60 mA @ 24 VDC

3a

Connect wires to unit as shown in Step 3.


Connect wires to your power source, making sure you connect positive to positive and negative to negative.


CAUTION!

Double check that you've wired from positive on Ascent to positive on your power source and negative on Ascent to negative on your power source.

Reverse polarity can damage Ascent!

Installing a Custom SIM Card (Optional)





Insert new SIM card until it locks in place with "click" sound.



Call us at (844) 259-8265 or visit summitcontrol.com/contact

We are available Mon-Fri / 8am-5pm Central.



© 2016 Security Brands, Inc. QSG-25C1-EN Rev. C (11/2016)